

NONEL[®] MS Connector

Technical Information



Application Recommendations (continued)

damage. The surface connectors contain detonators and are subject to detonation caused by abuse such as impact. Shock tube which has been cut, ruptured or damaged may cause misfires.

- **NEVER** drive any equipment over NONEL MS Connector blocks, detonating cord or shock tube.
- **ALWAYS** trim excess lengths of detonating cord from the NONEL MS Connector block after completing the connection of each block to the detonating cord. Tails of detonating cord lying across or adjacent to the shock tube between the connector blocks will interfere with the functioning of the assembly and may cause misfires.
- **ALWAYS** use in-hole delays to minimize the chance of surface cutoffs with NONEL MS Connectors.
- **NEVER** connect NONEL MS Connector units to detonating cord trunklines until all boreholes have been primed and loaded and the blast site has been cleared of personnel and equipment.
- To connect the NONEL MS Connector unit to a detonating cord trunkline, cut the trunkline at the point where the surface delay is needed. Attach the NONEL MS Connector detonator between the cut ends using the NONEL MS Connector blocks. Only one end of the trunkline is attached to each NONEL MS Connector block so that the shock tube attached to each block completes the connection between the trunkline ends.

Transportation, Storage and Handling

- NONEL MS Connector units must be transported, stored, handled and used in conformity with all federal, state, provincial and local laws and regulations.
- For maximum shelf life (3 years), NONEL MS Connector units must be stored in a cool, dry, well ventilated magazine. Explosive inventory should be rotated. Avoid using new materials before the old. For recommended good practices in transporting, storing, handling and using this product, see the booklet "Prevention of Accidents in the Use of Explosive Materials" packed inside each case and the Safety Library Publications of the Institute of Makers of Explosives.

Packaging

Quantity / Case	Case Type
60	B

- Case weight varies by delay; see case label for exact weight.

Case Dimensions

B 41 x 30 x 21 cm 16 x 12 x 8 3/8 in

Product Disclaimer Dyno Nobel Inc. and its subsidiaries disclaim any warranties with respect to this product, the safety or suitability thereof, or the results to be obtained, whether express or implied, INCLUDING WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND/OR OTHER WARRANTY. Buyers and users assume all risk, responsibility and liability whatsoever from any and all injuries (including death), losses, or damages to persons or property arising from the use of this product. Under no circumstances shall Dyno Nobel Inc. or any of its subsidiaries be liable for special, consequential or incidental damages or for anticipated loss of profits.

Dyno Nobel Inc.

2795 East Cottonwood Parkway, Suite 500, Salt Lake City, Utah 84121 USA
Phone 800-732-7534 Fax 801-328-6452 Web www.dynonobel.com

DYNO
Dyno Nobel

Groundbreaking Performance