



# NONEL<sup>®</sup> Lead Line

## Technical Information



### Application Recommendations (continued)

NONEL LEAD LINE as the primary initiator for NONEL blast rounds.

- **ALWAYS** trim at least 3 m [10 ft] of tubing before inserting into a nonelectric shock tube starting device or whenever dirt and/or moisture may have compromised the open tube ends before making a splice connection.
- **ALWAYS** replace the plastic tube closure over the open end of any NONEL LEAD LINE that remains on the spool and is intended to be used to make up another nonelectric starter assembly.
- **ALWAYS** make the final hook-up of the nonelectric starter assembly to the blast round only after all equipment and non-essential personnel are clear of the blast area.
- **ALWAYS** unspool NONEL LEAD LINE by hand if the starter assembly has been spliced to it and is attached to the blast round.
- **ALWAYS** keep any NONEL LEAD LINE tube ends sealed and free from dirt and moisture since dirt or moisture in the shock tube may cause a misfire.
- **NEVER** use NONEL LEAD LINE for in-hole use. NONEL LEAD LINE is for use outside the borehole only.
- **NEVER** attempt to knot different lengths of shock tube together. Shock tube will not initiate itself through knot connections. It must be spliced.
- **NEVER** remove the plastic tube closure from the NONEL LEAD LINE shock tube until just before splicing.
- **NEVER** attach the starter assembly to the blast round until after the LEAD LINE deployment is complete whenever NONEL LEAD LINE is to be unspooled by any method other than by hand,

### Application Recommendations (continued)

- **NEVER** run over NONEL LEAD LINE with equipment. This may damage the shock tube and may cause a misfire. **ALWAYS** replace the NONEL LEAD LINE if it is damaged.
- When making a nonelectric starter assembly using NONEL LEAD LINE, **ALWAYS** remove the plastic tube closure and save for later use. Splice two freshly-cut ends of NONEL shock tube together (one from the NONEL LEAD LINE and the other from the NONEL detonator) by inserting them into opposite ends of the plastic connector sleeve and pushing them toward one another until they are both at least ½ cm (¼ in) in the splice.

### Transportation, Storage and Handling

- NONEL LEAD LINE must be transported, stored, handled and used in conformity with all federal, state, provincial and local laws and regulations.
- For maximum shelf life (3 years), NONEL LEAD LINE must be stored in a cool, dry, well ventilated magazine. Explosive inventory should be rotated. Avoid using new materials before the old. For recommended good practices in transporting, storing, handling and using this product, see the booklet "Prevention of Accidents in the Use of Explosive Materials" packed inside each case and the Safety Library Publications of the Institute of Makers of Explosives.

### Case Dimensions

51 x 25 x 28 cm 20 x 9 7/8 x 10 7/8 in

**Product Disclaimer** Dyno Nobel Inc. and its subsidiaries disclaim any warranties with respect to this product, the safety or suitability thereof, or the results to be obtained, whether express or implied, INCLUDING WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND/OR OTHER WARRANTY. Buyers and users assume all risk, responsibility and liability whatsoever from any and all injuries (including death), losses, or damages to persons or property arising from the use of this product. Under no circumstances shall Dyno Nobel Inc. or any of its subsidiaries be liable for special, consequential or incidental damages or for anticipated loss of profits.

### Dyno Nobel Inc.

2795 East Cottonwood Parkway, Suite 500, Salt Lake City, Utah 84121 USA  
Phone 800-732-7534 Fax 801-328-6452 Web [www.dynonobel.com](http://www.dynonobel.com)

**DYNO**  
Dyno Nobel

Groundbreaking Performance