Explosives Engineers' Guide





Groundbreaking Performance[®]

DISCLAIMER

The explosive products discussed in this document should only be handled by persons with the appropriate technical skills, training and licences. While Dyno Nobel has made every effort to ensure the information in this document is correct, every user is responsible for understanding the safe and correct use of the products. If you need specific technical advice or have any questions, you should contact your Dyno Nobel representative. This information is provided without any warranty, express or implied, regarding its correctness or accuracy and, to the maximum extent permitted by law, Dyno Nobel expressly disclaims any and all liability arising from the use of this document or the information contained herein. It is solely the responsibility of the user to make enquiries, obtain advice and determine the safe conditions for use of the products referred to herein and the user assumes liability for any loss, damage, expense or cost resulting from such use.

Dyno Nobel Asia Pacific Pty Limited (ACN 003 269 010) is a subsidiary of Incitec Pivot Limited (ACN 004 080 264) Level 8, 28 Freshwater Place, Southbank VIC 3006

® DYNO, GROUNDBREAKING PERFORMANCE, TITAN, POWERMITE, DYNOSPLIT, FIRELINE, SANFOLD, Z-BAR, NONEL, RIGHT, RINGPRIME, PRIMACORD, PRIMALINE, TROJAN, 9000XERO, POWERMITE PLUS & POWERMITE THERMO are registered trademarks of the Dyno Nobel / Incitec Pivot Limited Group.

SMARTSHOT, DRIFTSHOT, DIGISHOT and BLASTWEB are registered trademarks of DetNet South Africa (Pty) Limited.

- ™ BLAST HI-T, STINGER EXPLODER, STEMPAC, SUPER STARTER, DYNOSTART and DYNOTRACKER are trademarks of the Dyno Nobel / Incitec Pivot Group.
- © Dyno Nobel Asia Pacific Pty Limited 2020. Reproduction without permission is strictly prohibited.

REF0168/1019/AZZAUS/1000

The information provided in this brochure is confidential. It may not be disclosed to any person without the express written consent of Dyno Nobel Asia Pacific Pty Limited.

You may only use this information if you are a customer of Dyno Nobel and you have been provided with it directly by an authorised representative of Dyno Nobel.

Take 5!

Rapid Hazard Assessment



Is the task new?

Describe the task.

- Is anything different?
- Has anything changed since you last performed this task?
- If so, STOP, THINK and apply the Take 5 steps!

What is the task you are about to do?



- 2 List the Hazards. What are the main hazards involved in carrying out the task?
- 3 List the controls. What controls will you use to reduce the risk?
- 4 Assess the risk. Use the Hazard Assessment Tool (HAT) to determine the risk after controls are applied.



5 Decide what is next. Apply the controls. Is it safe to proceed with the task? Are additional controls required?

Glossary

Airblast Airborne shock wave resulting from the detonation of explosives.

Back break Rock broken beyond the limits of the last row.

Blasthole pressure The pressure which the gasses of detonation exert on the blasthole wall.

Burden The distance between adjacent rows.

Charge weight The amount of explosive charge in kilograms.

Column charge A continuous charge of explosives in a blasthole.

Critical diameter The minimum diameter for propagation of a stable detonation.

Cutoffs A portion of an explosive column that has failed to detonate due to rock movement.

Decoupling The use of explosive products having smaller volume than the volume of the blasthole it occupies.

Delay blasting The use of delay detonators or connectors to separate charges by a defined time.

Density Mass per unit volume.

Detonation pressure The pressure created in the reaction zone of a detonating explosive.

Explosive Any chemical or mixture of chemicals that can react to produce an explosion.

Free face A rock surface that provides the rock with room to expand when blasted.

Flyrock Rock that is propelled through air from a blast.

Fragmentation Measure to describe the size of distribution of broken rock after blasting.

Ground vibration Ground movement caused by the stress waves emanating from a blast. Initiation The act of detonating explosives by any means.

Line drilling A method of overbreak control which uses a series of closely spaced holes that are not charged.

Loading density The weight of explosives per metre of blasthole.

Maximum Instantaneous Charge (MIC) Mass of explosive detonating in some defined time period, usually 8 milliseconds.

Overbreak Excessive breakage of rock beyond the desired excavation limit.

Particle velocity The speed of movement in a given direction of a rock or soil mass.

Pre-split A controlled blast in which decoupled charges are fired in holes on the perimeter of the excavation prior to the main firing.

Relative Bulk Strength (RBS) The energy yield per unit volume of an explosive compared to ANFO.

Relative Weight Strength (RWS) The energy yield per unit mass of an explosive compared to ANFO.

Spacing The distance between blastholes in the same row.

Stemming Inert material used to confine the gasses generated during detonation.

Swell factor The ratio of the volume of broken rock to the volume of in-situ rock.

Velocity of Detonation (VoD) The velocity at which a detonation progresses through an explosive.

Blast design terminology and formulas

Drilled Bur Bench Height (BH) Floor	Dimed Spacing (3	meter (D) Backbreak New Crest (After Mucking)
Hole length (L) =	BH + SD	

Hole len	gui (L) =	BH + 2	U	
Charge I	ength (C) =	L – SL		
Blast vo	lume (V) =	ВхSх	BH x N	
Blasted	tonnes (T) =	V x Den	sity of ro	ck in t/m³
Volume	of blasthole (Vb) =	π x D ² /4	4000 x L	
Mass of	explosive per hole (kg) =	Volume	of hole le	ength charged x Explosive density
PF (kg/n	1 ³) =	Total ex	plosives i	n the blast/blast volume
PF (kg/t)	=	Total ex	plosives i	n the blast/blasted tonnes
RWS =		AWS of	explosive	AWS of ANFO x 100
RBS =		(RWS e	xplosive x	explosive density)/(ANFO density)
Energy f	actor =	PF x RV	VS	
Vertical	length of angled holes =	Measur	ed hole le	ength x cos ∝
∝ =	Angle subtended from the v	ertical	L =	Hole length (m)
	by the inclined hole		N =	Number of holes in a blast
π =	3.1416 (the ratio of the		PF =	Powder factor
	circumference of a circle		RBS =	Relative bulk strength
	to its diameter)		RWS =	Relative weight strength
AWS =	Absolute weight strength		S =	Drilled spacing (m)
B =	Drilled burden (m)		SD =	Subdrill (m)
BH =	Bench height (m)		SL =	Stemming length (m)

- Explosive column height or charge C = length (m) D =
- SL = T = Blasted tonnes V = Blast volume (m³) Hole diameter in millimetres

Rules of thumb

These rules provide a first estimate in the absence of any better data.

Blasthole diameter in mm \leq	15 x Bench height (BH) in metres
Bench height (BH) in metres ≥	(Blasthole diameter (D) in mm)/15
Burden (B) =	(25 to 40) x (D)
Spacing (S) =	1.15 x B (This gives an equilateral pattern)
Subdrill =	(3 to 15) x D
Charge length (C) ≥	20 D
Stemming ≥	20 x D or (0.7 - 1.2) x B
Burden stiffness ratio =	BH/B : 2 to 3.5 good fragmentation
	: > 3.5 very good fragmentation
Stemming material size =	D/10 to D/20 (Angular material with minimum fines)

Presplit blasting

Spacing =	Hole diameter x 12
Burden =	0.5 x production blast burden (B)
Uncharged length at top =	10 x D
Powder factor =	0.5kg per square metre of face

Do not stem holes.

Fire all holes on the same delay, or in groups of \geq 5 holes

Smooth blasting

Spacing =	15 x Hole diameter (hard rock)
	20 x Hole diameter (soft rock)
Burden =	1.25 x Spacing

Fire as many holes as possible on one delay. Stem holes.

Powder factors

Typical powder factors used in mass blasts


Rock type	PF (kg/m ³)
Hard	0.7 - 0.8
Medium	0.4 - 0.5
Soft	0.25 - 0.35
Very Soft	0.15 - 0.25

Typical powder factors used in presplit and smooth blasting

Hole diameter	PF (kg/m ²)
Hard	0.6 - 0.9
Medium	0.4 - 0.5
Soft	0.2 - 0.3

Angle faced holes

Calculating burdens



Crest Burden (CB)	 Distance blasthole collar is from crest
Vertical Stemming Length (VSL)	= (measured stemming length x cos [HA])
Toe Burden (TB)	= Burden at floor level
	= ([tan (FA) x bench height] + CB) -
	(tan [HA] x bench height)

Volume table

1.00 1.25 1.50 1.00 1.25 1.50 1.00 1.26 1.88 1.25 1.56 1.88 1.50 1.88 2.25																						(Metres)
1.25 1.56 1.88	1.75	2.00	2.25	2.50	2.75	3.00	3.50	4.00	4.50	5.00	6.00	6.50	7.00	7.50	8.00	8.50	9.00	9.50	10.00	10.00 11.00 12.00	12.00	
1.56 1.88	1.75	2.00	2.25	2.50	2.75	3.00	3.50	4.00	4.50													1.00
1.88	2.19	2.50	2.81	3.13	3.44	3.75	4.38	5.00	5.63	6.25												1.25
	2.63	3.00	3.38	3.75	4.13	4.50	5.25	6.00	6.75	7.50	9.00											1.50
2.00 2.50 3.00	3.50	4.00	4.50	5.00	5.50	6.00	7.00	8.00	9.00	10.00	12.00	13.00										2.00
2.25 2.81 3.38	3.94	4.50	5.06	5.63	6.19	6.75	7.88	9.00	10.13	11.25	13.50	14.63	15.75									2.25
2.50 3.13 3.75	4.38	5.00	5.63	6.25	6.88	7.50	8.75	10.00	11.25	12.50	15.00	16.25	17.50	18.75								2.50
2.75 3.44 4.13	4.81	5.50	6.19	6.88	7.56	8.25	9.63	11.00	12.38	13.75	16.50	17.88	19.25	20.63	22.00							2.75
3.00 3.75 4.50	5.25	6.00	6.75	7.50	8.25	9.00	10.50	12.00	13.50	15.00	18.00	19.50	21.00	22.50	24.00	5.50						3.00
4.38 5.25	6.13	7.00	7.88	8.75	9.63	10.50	12.25	14.00	15.75	17.50	21.00	22.75	24.50	26.25	28.00	29.75	31.50					3.50
5.00 6.00	7.00	8.00	9.00	10.00	11.00	12.00	14.00	16.00	18.00	20.00	24.00	26.00	28.00	30.00	32.00	34.00	36.00	38.00				4.00
5.63 6.75	7.88	9.00	10.13	11.25	12.38	13.50	15.75	18.00	20.25	22.50	27.00	29.25	31.50	33.75	36.00	38.25	40.50	42.75	45.00			4.50
7.50	8.75	10.00	11.25	12.50	13.75	15.00	17.50	20.00	22.50	25.00	30.00	32.50	35.00	37.50	40.00	42.50	45.00	47.50	50.00	55.00		5.00
9.00	10.50	12.00	13.50	15.00	16.50	18.00	21.00	24.00	27.00	30.00	36.00	39.00	42.00	45.00	48.00	51.00	54.00	57.00	60.00	66.00	72.00	6.00
	11.38	13.00	14.63	16.25	17.88	19.50	22.75	26.00	29.25	32.50	39.00	42.25	45.50	48.75	52.00	55.25	58.50	61.75	65.00	71.50	78.00	6.50
	12.25	14.00	15.75	17.50	19.25	21.00	24.50	28.00	31.50	35.00	42.00	45.50	49.00	52.50	56.00	59.50	63.00	66.50	70.00	77.00	84.00	7.00
	13.13	15.00	16.88	18.75	20.63	22.50	26.25	30.00	33.75	37.50	45.00	48.75	52.50	56.25	60.00	63.75	67.50	71.25	75.00	82.50	90.00	7.50
		16.00	18.00	20.00	22.00	24.00	28.00	32.00	36.00	40.00	48.00	52.00	56.00	60.00	64.00	68.00	72.00	76.00	80.00	88.00	96.00	8.00
		17.00	19.13	21.25	23.38	25.50	29.75	34.00	38.25	42.50	51.00	55.25	59.50	63.75	68.00	72.25	76.50	80.75	85.00	93.50 102.00	02.00	8.50
		18.00	20.25	22.50	24.75	27.00	31.50	36.00	40.50	45.00	54.00	58.50	63.00	67.50	72.00	76.50	81.00	85.50	90.00	99.00 108.00	08.00	9.00
			21.38	23.75	26.13	28.50	33.25	38.00	42.75	47.50	57.00	61.75	66.50	71.25	76.00	80.75	85.50	90.25		95.00 104.50 114.00	14.00	9.50
			22.50	25.00	27.50	30.00	35.00	40.00	45.00	50.00	60.00	65.00	70.00	75.00	80.00	85.00	90.00	95.00	100.00 110.00 120.00	110.001	20.00	10.00
			24.75	27.50	30.25	33.00	38.50	44.00	49.50	55.00	66.00	71.50	77.00	82.50	88.00	93.50	. 00'66	104.50	99.00 104.50 110.00 121.00 132.00	121.00 1	32.00	11.00
				30.00	33.00	36.00	42.00	48.00	54.00	60.00	72.00	78.00	84.00	90.00	96.00	102.00	102.00 108.00 114.00 120.00 132.00 144.00	114.00	120.00	132.00 1	44.00	12.00

ameter	•	-	11/4	11/2	1 3/4	2	2 1/4	21/2	2 3/4	ŝ	3 1/4	3 1/2	3 3/4	4	41/4	41/2	4 3/4	5	5 1/4	51/2	5 3/4	9	6 1/4	6 1/2	6 3/4	7	7 3/8	7 7/8	8	8 1/2	6	9 1/2	10	10 5/8	÷	12 1/4	15	17 1/2
Hole Diameter		25	32	8	45	51	57	64	20	76	83	89	95	102	108	114	121	127	133	140	146	152	159	165	172	178	187	200	203	216	229	251	254	270	279	311	381	445
	1.40	0.69	1.13	1.59	2.23	2.86	3.57	4.50	5.39	6.35	7.57	8.71	9.92	11.44	12.83	14.29	16.10	17.73	19.45	21.55	23.44	25.40	27.80	29.94	32.53	34.84	38.45	43.98	45.31	51.30	57.66	69.27	70.94	80.16	85.59	106.35	159.61	217.74
	1.35	0.66	1.09	1.53	2.15	2.76	3.44	4.34	5.20	6.12	7.30	8.40	9.57	11.03	12.37	13.78	15.52	17.10	18.76	20.78	22.60	24.50	26.81	28.87	31.37	33.59	37.08	42.41	43.69	49.47	55.60	66.80	68.41	77.29	82.53	102.55	153.91	209.96
	1.30	0.64	1.05	1.47	2.07	2.66	3.32	4.18	5.00	5.90	7.03	8.09	9.21	10.62	11.91	13.27	14.95	16.47	18.06	20.01	21.76	23.59	25.81	27.80	30.21	32.35	35.70	40.84	42.08	47.64	53.54	64.33	65.87	74.43	79.48	98.75	148.21	202.19
m³)*	1.20	0.59	0.97	1.36	1.91	2.45	3.06	3.86	4.62	5.44	6.49	7.47	8.51	9.81	10.99	12.25	13.80	15.20	16.67	18.47	20.09	21.78	23.83	25.66	27.88	29.86	32.96	37.70	38.84	43.97	49.42	59.38	60.80	68.71	73.36	91.16	136.81	186.63
explosive per meter of column for given density (g/cm^3)	1.15	0.56	0.92	1.30	1.83	2.35	2.93	3.70	4.43	5.22	6.22	7.15	8.15	9.40	10.54	11.74	13.22	14.57	15.98	17.70	19.25	20.87	22.83	24.59	26.72	28.62	31.58	36.13	37.22	42.14	47.37	56.90	58.27	65.84	70.31	87.36	131.11	178.86
given der	1.10	0.54	0.88	1.25	1.75	2.25	2.81	3.54	4.23	4.99	5.95	6.84	7.80	8.99	10.08	11.23	12.65	13.93	15.28	16.93	18.42	19.96	21.84	23.52	25.56	27.37	30.21	34.56	35.60	40.31	45.31	54.43	55.74	62.98	67.25	83.56	125.41	171.08
olumn for	1.05	0.52	0.84	1.19	1.67	2.14	2.68	3.38	4.04	4.76	5.68	6.53	7.44	8.58	9.62	10.72	12.07	13.30	14.59	16.16	17.58	19.05	20.85	22.45	24.40	26.13	28.84	32.99	33.98	38.48	43.25	51.95	53.20	60.12	64.19	79.76	119.71	163.30
leter of co	1.00	0.49	0.80	1.13	1.59	2.04	2.55	3.22	3.85	4.54	5.41	6.22	7.09	8.17	9.16	10.21	11.50	12.67	13.89	15.39	16.74	18.15	19.86	21.38	23.24	24.88	27.46	31.42	32.37	36.64	41.19	49.48	50.67	57.26	61.14	75.96	114.01	155.53
ive per m	0.95	0.47	0.76	1.08	1.51	1.94	2.42	3.06	3.66	4.31	5.14	5.91	6.73	7.76	8.70	9.70	10.92	12.03	13.20	14.62	15.90	17.24	18.86	20.31	22.07	23.64	26.09	29.85	30.75	34.81	39.13	47.01	48.14	54.39	58.08	72.17	108.31	147.75
ъ	0.90	0.44	0.72	1.02	1.43	1.84	2.30	2.90	3.46	4.08	4.87	5.60	6.38	7.35	8.24	9.19	10.35	11.40	12.50	13.85	15.07	16.33	17.87	19.24	20.91	22.40	24.72	28.27	29.13	32.98	37.07	44.53	45.60	51.53	55.02	68.37	102.61	139.98
Кg	0.85	0.42	0.68	0.96	1.35	1.74	2.17	2.73	3.27	3.86	4.60	5.29	6.02	6.95	7.79	8.68	9.77	10.77	11.81	13.08	14.23	15.42	16.88	18.18	19.75	21.15	23.34	26.70	27.51	31.15	35.01	42.06	43.07	48.67	51.97	64.57	96.91	132.20
	0.82	0.40	0.66	0.93	1.30	1.68	2.09	2.64	3.16	3.72	4.44	5.10	5.81	6.70	7.51	8.37	9.43	10.39	11.39	12.62	13.73	14.88	16.28	17.53	19.05	20.41	22.52	25.76	26.54	30.05	33.77	40.57	41.55	46.95	50.13	62.29	93.49	127.53
	0.80	0.39	0.64	0.91	1.27	1.63	2.04	2.57	3.08	3.63	4.33	4.98	5.67	6.54	7.33	8.17	9.20	10.13	11.11	12.32	13.39	14.52	15.88	17.11	18.59	19.91	21.97	25.13	25.89	29.31	32.95	39.58	40.54	45.80	48.91	60.77	91.21	124.42
	0.60	0.29	0.48	0.68	0.95	1.23	1.53	1.93	2.31	2.72	3.25	3.73	4.25	4.90	5.50	6.12	6.90	7.60	8.34	9.24	10.04	10.89	11.91	12.83	13.94	14.93	16.48	18.85	19.42	21.99	24.71	29.69	30.40	34.35	36.68	45.58	68.41	93.32
Diameter	•		1 1/4	1 1/2	1 3/4	2	2 1/4	2 1/2	2 3/4	ŝ	3 1/4	3 1/2	3 3/4	4	4 1/4	4 1/2	4 3/4	5	5 1/4	5 1/2	5 3/4	9	6 1/4	6 1/2	6 3/4	7	7 1/4	7 1/2	8	8 1/2	6	9 1/2	10	10 1/2	÷	12 1/4	15	17 1/2
Hole D		25 25	32	88	45	21	22	64	202	20	83	89	92 and	ž 102	108	114	121	127	133	140	146	152	159	165	172	178	187	₽ 200	203	216	229	251	254	270	279	311	381	445

Loading density

*For non-gassed products only. The density of gassed products varies according to depth in an explosive column and the open cup density. Please consult the "Gassing density for Titan blends" table for further information. D is the hole diameter in mm P is the explosive density in a/cm³

Where

Calculation Ko/m = 3.14159 x D² x P / 4.000

Dyno Nobel Mobile App

- Explosives Engineers' Guide
- Interactive Blasting Calculators
- Dyno Nobel Product Specifications
- Accessible Anytime, Anywhere
- Real Time Dyno Nobel News and Products
- GPS Enabled
- For iPhone, iPad and Android Devices

For more information go to www.dynonobel.com

FREE DOWNLOAD





Groundbreaking Performance[®]

Gassing density for TITAN[®] blends

Density of TITAN 2050 and TITAN 2050G blends in an explosive column at different depths for different open cup densities.

		Т	TAN 2050G I	Density g/c	m ³		Unga	ssed
Depth (m)	Avg. In-Hole	Toe	Avg. In-Hole	Toe	Avg. In-Hole	Toe	Avg. In-Hole	Toe
Open Cup	1.10	1.10	1.15	1.15	1.20	1.20	1.31	1.31
1	1.12	1.13	1.16	1.18	1.21	1.23	1.32	1.33
2	1.13	1.16	1.18	1.20	1.22	1.25	1.32	1.34
3	1.14	1.19	1.19	1.23	1.23	1.26	1.33	1.35
4	1.16	1.21	1.20	1.24	1.24	1.28	1.34	1.36
5	1.17	1.22	1.21	1.26	1.25	1.29	1.34	1.36
6	1.18	1.24	1.22	1.27	1.26	1.30	1.34	1.37
7	1.19	1.25	1.23	1.28	1.27	1.31	1.35	1.37
8	1.20	1.26	1.23	1.29	1.27	1.32	1.35	1.38
9	1.20	1.28	1.24	1.30	1.28	1.33	1.35	1.38
10	1.21	1.29	1.25	1.31	1.28	1.33	1.36	1.39
11	1.22	1.29	1.25	1.32	1.29	1.34	1.36	1.39
12	1.22	1.30	1.26	1.32	1.29	1.35	1.36	1.39
13	1.23	1.31	1.26	1.33	1.30	1.35	1.36	1.39
14	1.24	1.32	1.27	1.34	1.30	1.36		
15	1.24	1.32	1.27	1.34	1.30	1.36		
16	1.25	1.33	1.28	1.35	1.31	1.36		
17	1.25	1.33	1.28	1.35	1.31	1.37		
18	1.26	1.34	1.29	1.35	1.31	1.37		
19	1.26	1.34	1.29	1.36	1.32	1.37		
20	1.26	1.34	1.29	1.36	1.32	1.38		
22	1.27	1.35	1.30	1.37	1.32	1.38		
24	1.27	1.36	1.30	1.37	1.32	1.38		
26	1.28	1.36	1.30	1.38	1.33	1.39		
28	1.28	1.37	1.31	1.38	1.33	1.39		
30	1.28	1.37	1.31	1.38	1.33	1.39		
32	1.29	1.38	1.31	1.39				
34	1.29	1.38	1.31	1.39				
36	1.29	1.38	1.32	1.39				
38	1.30	1.38	1.32	1.39				
40	1.30	1.39						
45	1.30	1.39						
50	1.30	1.39						
55	1.31	1.39						
60	1.31	1.39						

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry or dewatered hole conditions.
- This table applies for TITAN 2000 Matrix blends with an emulsion content of 50% w/w ONLY, i.e. T2050G and T2050.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in a vertical blasthole, and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (a Toe density of 1.39g/cm³ in the 1.10g/cm³ open cup density column). This indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density of 1.10g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the shaded column (an Avg. In-Hole density of 1.30g/cm³ in the 1.10 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth e.o. a 25m deep hole should be rounded to 26m and corresponding densities apolled.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU operator to achieve the associated open cup density.
- The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is necessary to allow at least this time to elapse following completion of loading and before stemming the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.
- The low density explosive grade ammonium nitrate used in the model was assigned a bulk density of 0.77 g/cm³ and a particle density of 1.58 g/cm³.

Gassing density for TITAN® blends

Density of TITAN 2060G blends in an explosive column at different depths for different open cup densities.

					т	ITAN	2060G D	ensity	/g/cm ³					
	Avg.		Avg.		Avg.		Avg.		Avg.		Avg.		Avg.	
Depth (m)		Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe
Open Cup	0.90	0.90	0.95	0.95	1.00	1.00	1.05	1.05	1.10	1.10	1.15	1.15	1.20	1.20
1	0.92	0.94	0.97	0.99	1.02	1.04	1.07	1.08	1.12	1.13	1.16	1.18	1.21	1.22
2	0.94	0.98	0.99	1.02	1.04	1.07	1.08	1.11	1.13	1.16	1.18	1.20	1.22	1.24
3	0.96	1.01	1.00	1.06	1.05	1.10	1.10	1.14	1.14	1.18	1.19	1.22	1.23	1.26
4	0.97	1.04	1.02	1.08	1.07	1.12	1.11	1.16	1.15	1.20	1.20	1.24	1.24	1.27
5	0.99	1.07	1.03	1.11	1.08	1.14	1.12	1.18	1.16	1.22	1.21	1.25	1.25	1.28
6	1.00	1.09	1.05	1.13	1.09	1.16	1.13	1.20	1.17	1.23	1.21	1.26	1.25	1.29
7	1.02	1.11	1.06	1.15	1.10	1.18	1.14	1.21	1.18	1.24	1.22	1.27	1.26	1.30
8	1.03	1.13	1.07	1.16	1.11	1.19	1.15	1.22	1.19	1.25	1.23	1.28	1.26	1.31
9	1.04	1.15	1.08	1.18	1.12	1.21	1.16	1.24	1.20	1.26	1.23	1.29	1.27	1.32
10	1.05	1.16	1.09	1.19	1.13	1.22	1.17	1.25	1.20	1.27	1.24	1.30	1.27	1.32
11	1.06	1.18	1.10	1.20	1.14	1.23	1.17	1.26	1.21	1.28	1.25	1.30	1.28	1.33
12	1.07	1.19	1.11	1.21	1.15	1.24	1.18	1.26	1.22	1.29	1.25	1.31	1.28	1.33
13	1.08	1.20	1.12	1.22	1.15	1.25	1.19	1.27	1.22	1.29	1.25	1.32	1.29	1.34
14	1.09	1.21	1.13	1.23	1.16	1.26	1.19	1.28	1.23	1.30	1.26	1.32	1.29	1.34
15	1.10	1.22	1.13	1.24	1.17	1.26	1.20	1.29	1.23	1.31	1.26	1.33	1.29	1.34
16	1.11	1.23	1.14	1.25	1.17	1.27	1.21	1.29	1.24	1.31	1.27	1.33	1.30	1.35
17	1.11	1.24	1.15	1.26	1.18	1.28	1.21	1.30	1.24	1.32	1.27	1.33	1.30	1.35
18	1.12	1.24	1.15	1.26	1.18	1.28	1.22	1.30	1.25	1.32	1.27	1.34	1.30	1.35
19	1.13	1.25	1.16	1.27	1.19	1.29	1.22	1.31	1.25	1.32	1.28	1.34	1.31	1.36
20	1.13	1.26	1.16	1.28	1.19	1.29	1.22	1.31	1.25	1.33	1.28	1.34	1.31	1.36
22	1.14	1.27	1.17	1.29	1.20	1.30	1.23	1.32	1.26	1.33	1.28	1.35	1.31	1.36
24	1.15	1.28	1.18	1.30	1.20	1.31	1.23	1.33	1.26	1.34	1.29	1.35	1.31	1.37
26	1.15	1.29	1.18	1.30	1.21	1.32	1.24	1.33	1.26	1.34	1.29	1.36	1.32	1.37
28	1.16	1.30	1.19	1.31	1.21	1.32	1.24	1.34	1.27	1.35	1.29	1.36	1.32	1.37
30	1.16	1.30	1.19	1.32	1.22	1.33	1.24	1.34	1.27	1.35	1.30	1.36		
32	1.17	1.31	1.20	1.32	1.22	1.33	1.25	1.35	1.27	1.36	1.30	1.37		
34	1.17	1.32	1.20	1.33	1.23	1.34	1.25	1.35	1.28	1.36	1.30	1.37		
36	1.18	1.32	1.20	1.33	1.23	1.34	1.26	1.35	1.28	1.36	1.30	1.37		
38	1.18	1.33	1.21	1.34	1.23	1.35	1.26	1.36	1.28	1.37	1.31	1.37		
40	1.19	1.33	1.21	1.34	1.24	1.35	1.26	1.36	1.29	1.37				
45	1.19	1.33	1.22	1.34	1.24	1.35	1.27	1.36	1.29	1.37				
50	1.20	1.33	1.22	1.34	1.25	1.35	1.27	1.36	1.29	1.37				
55	1.20	1.34	1.23	1.35	1.25	1.35	1.27	1.36	1.29	1.37				
60	1.21	1.34	1.23	1.35	1.25	1.36	1.27	1.36	1.29	1.37				

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry hole conditions. In wet hole conditions, the value selected from the left hand column must be the sum of the product column and the height of the water column in the hole. If the length of the product and water column exceeds the depth of the hole then the value selected from the left hand column must be the hole depth.
- This table applies for TITAN 2000 Matrix blends with an emulsion content of 60% w/w ONLY, i.e. T2060G.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in a vertical blasthole, and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (a Toe density of 1.37g/cm³ in the 1.10 g/cm³ open cup density column). This indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density of 1.30g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the shaded column (an Avg. In-Hole density of 1.29g/cm³ in the 1.10 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth. e.g. a 25m deep hole should be rounded to 26m and corresponding densities applied.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU operator to achieve the associated open cup density.
- The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is necessary to allow at least this time to elapse following completion of loading and before stemming the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.
- The low density explosive grade ammonium nitrate used in the model was assigned a bulk density of 0.77 g/cm³ and a particle density of 1.58 g/cm³.

Gassing density for TITAN[®] blends

Density of TITAN 2070G blends in an explosive column at different depths for different open cup densities.

						TITAN	2070G D	ensity	g/cm ³					
	Avg.		Avg.		Avg.		Avg.		Avg.		Avg.		Avg.	
Depth (m)		Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe
Open Cup	0.90	0.90	0.95	0.95	1.00	1.00	1.05	1.05	1.10	1.10	1.15	1.15	1.20	1.20
1	0.92	0.94	0.97	0.99	1.02	1.04	1.07	1.08	1.11	1.13	1.16	1.17	1.21	1.22
2	0.94	0.98	0.99	1.02	1.03	1.07	1.08	1.11	1.13	1.15	1.17	1.20	1.22	1.24
3	0.96	1.01	1.00	1.05	1.05	1.09	1.09	1.13	1.14	1.17	1.18	1.21	1.23	1.25
4	0.97	1.03	1.02	1.08	1.06	1.12	1.11	1.15	1.15	1.19	1.19	1.23	1.23	1.26
5	0.99	1.06	1.03	1.10	1.07	1.14	1.12	1.17	1.16	1.21	1.20	1.24	1.24	1.27
6	1.00	1.08	1.04	1.12	1.09	1.15	1.13	1.19	1.17	1.22	1.21	1.25	1.25	1.28
7	1.01	1.10	1.05	1.14	1.10	1.17	1.14	1.20	1.18	1.23	1.21	1.26	1.25	1.29
8	1.02	1.12	1.07	1.15	1.11	1.18	1.14	1.21	1.18	1.24	1.22	1.27	1.26	1.30
9	1.04	1.14	1.08	1.17	1.11	1.20	1.15	1.22	1.19	1.25	1.23	1.28	1.26	1.30
10	1.05	1.15	1.08	1.18	1.12	1.21	1.16	1.23	1.20	1.26	1.23	1.28	1.27	1.31
11	1.06	1.16	1.09	1.19	1.13	1.22	1.17	1.24	1.20	1.27	1.24	1.29	1.27	1.31
12	1.06	1.17	1.10	1.20	1.14	1.23	1.17	1.25	1.21	1.27	1.24	1.30	1.27	1.32
13	1.07	1.19	1.11	1.21	1.15	1.23	1.18	1.26	1.21	1.28	1.25	1.30	1.28	1.32
14	1.08	1.20	1.12	1.22	1.15	1.24	1.19	1.26	1.22	1.29	1.25	1.31	1.28	1.33
15	1.09	1.20	1.12	1.23	1.16	1.25	1.19	1.27	1.22	1.29	1.25	1.31	1.28	1.33
16	1.10	1.21	1.13	1.24	1.16	1.26	1.20	1.28	1.23	1.30	1.26	1.31	1.29	1.33
17	1.10	1.22	1.14	1.24	1.17	1.26	1.20	1.28	1.23	1.30	1.26	1.32	1.29	1.33
18	1.11	1.23	1.14	1.25	1.17	1.27	1.20	1.29	1.23	1.30	1.26	1.32	1.29	1.34
19	1.12	1.23	1.15	1.25	1.18	1.27	1.21	1.29	1.24	1.31	1.27	1.32	1.29	1.34
20	1.12	1.24	1.15	1.26	1.18	1.28	1.21	1.29	1.24	1.31	1.27	1.33	1.30	1.34
22	1.13	1.25	1.16	1.27	1.19	1.29	1.22	1.30	1.25	1.32	1.27	1.33	1.30	1.35
24	1.13	1.26	1.16	1.28	1.19	1.29	1.22	1.31	1.25	1.32	1.28	1.34	1.30	1.35
26	1.14	1.27	1.17	1.29	1.20	1.30	1.22	1.31	1.25	1.33	1.28	1.34	1.30	1.35
28	1.15	1.28	1.17	1.29	1.20	1.31	1.23	1.32	1.25	1.33	1.28	1.34	1.31	1.35
30	1.15	1.28	1.18	1.30	1.21	1.31	1.23	1.32	1.26	1.33	1.28	1.35		
32	1.16	1.29	1.18	1.30	1.21	1.32	1.24	1.33	1.26	1.34	1.29	1.35		
34	1.16	1.30	1.19	1.31	1.21	1.32	1.24	1.33	1.26	1.34	1.29	1.35		
36	1.17	1.30	1.19	1.31	1.22	1.32	1.24	1.33	1.27	1.34	1.29	1.35		
38	1.17	1.31	1.20	1.32	1.22	1.33	1.25	1.34	1.27	1.35				
40	1.17	1.31	1.20	1.32	1.22	1.33	1.25	1.34	1.27	1.35				
45	1.18	1.31	1.20	1.32	1.23	1.33	1.25	1.34	1.27	1.35				
50	1.18	1.31	1.21	1.32	1.23	1.33	1.25	1.34	1.28	1.35				
55	1.19	1.32	1.21	1.33	1.23	1.33	1.26	1.34	1.28	1.35				
60	1.19	1.32	1.21	1.33	1.24	1.34	1.26	1.34	1.28	1.35				

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry hole conditions. In wet hole conditions, the value selected from the left hand column must be the sum of the product column plus the height of the water column in the hole. If the length of the product and water column exceeds the depth of the hole then the value selected from the left hand column must be the hole depth.
- This table applies for TITAN 2000 Matrix blends with an emulsion content of 70% w/w ONLY, i.e. T2070G.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in a vertical blasthole, and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (a Toe density of 1.35g/cm³ in the 1.10 g/cm³ open cup density column). This indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density of 1.10g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the shaded column (an Avg. In-Hole density of 1.27g/cm³ in the 1.10 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth. e.g. a 25m deep hole should be rounded to 26m and corresponding densities applied.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU operator to achieve the associated open cup density.
- The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is
 necessary to allow at least this time to elapse following completion of loading and before stemming
 the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.
- The low density explosive grade ammonium nitrate used in the model was assigned a bulk density of 0.77 g/cm³ and a particle density of 1.58 g/cm³.

Gassing density for TITAN® blends

Density of gas sensitised and ungassed blends containing 50% TITAN 3000, TITAN 5000 or TITAN 9000 in an explosive column at different depths for different open cup densities.

	Gass	ed blend co	ontaining 50	% emulsion	– Density g	/cm ³	Unga	issed
	Avg.		Avg.		Avg.		Avg.	
Depth (m)	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe
Open Cup	1.10	1.10	1.15	1.15	1.20	1.20	1.32	1.32
1	1.12	1.13	1.17	1.18	1.21	1.23	1.33	1.34
2	1.13	1.16	1.18	1.21	1.23	1.25	1.33	1.35
3	1.15	1.19	1.19	1.23	1.24	1.27	1.34	1.36
4	1.16	1.21	1.20	1.25	1.25	1.28	1.35	1.37
5	1.17	1.23	1.21	1.26	1.25	1.30	1.35	1.37
6	1.18	1.25	1.22	1.28	1.26	1.31	1.36	1.38
7	1.19	1.26	1.23	1.29	1.27	1.32	1.36	1.39
8	1.20	1.27	1.24	1.30	1.28	1.33	1.36	1.39
9	1.21	1.28	1.25	1.31	1.28	1.34	1.37	1.40
10	1.22	1.29	1.25	1.32	1.29	1.34	1.37	1.40
11	1.22	1.30	1.26	1.33	1.29	1.35	1.37	1.40
12	1.23	1.31	1.26	1.33	1.30	1.36		
13	1.24	1.32	1.27	1.34	1.30	1.36		
14	1.24	1.32	1.27	1.35	1.31	1.37		
15	1.25	1.33	1.28	1.35	1.31	1.37		
16	1.25	1.34	1.28	1.36	1.31	1.37		
17	1.26	1.34	1.29	1.36	1.32	1.38		
18	1.26	1.35	1.29	1.36	1.32	1.38		
19	1.27	1.35	1.30	1.37	1.32	1.38		
20	1.27	1.36	1.30	1.37	1.33	1.39		
22	1.28	1.36	1.30	1.38	1.33	1.39		
24	1.28	1.37	1.31	1.38	1.33	1.40		
26	1.28	1.37	1.31	1.39	1.34	1.40		
28	1.29	1.38	1.31	1.39	1.34	1.40		
30	1.29	1.38	1.32	1.40				
32	1.29	1.39	1.32	1.40				
34	1.30	1.39	1.32	1.40				
36	1.30	1.39	1.33	1.40				
38	1.30	1.40						
40	1.31	1.40						
45	1.31	1.40						
50	1.31	1.40						
55	1.32	1.40						
60	1.32	1.40						

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry or dewatered hole conditions.
- This table applies for TITAN 3000, TITAN 5000 and TITAN 9000 Matrix blends with an emulsion content of 50% w/w ONLY, i.e. T9050/T9050G.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in vertical and near vertical blastholes and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (a Toe density of 1.40g/cm³ in the 1.10 g/cm³ open cup density column). This indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density of 1.10g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the shaded column (an Avg. In-Hole density of 1.31g/cm³ in the 1.10 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth. e.g. a 25m deep hole should be rounded to 26m and corresponding densities applied.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU operator to achieve the associated open cup density.
- The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is
 necessary to allow at least this time to elapse following completion of loading and before stemming
 the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.
- The low density explosive grade ammonium nitrate used in the model was assigned a bulk density of 0.77 g/cm³ and a particle density of 1.58 g/cm³.

Gassing density for TITAN[®] blends

Density of gas sensitised blends containing 60% TITAN 3000, TITAN 5000 or TITAN 9000 in an explosive column at different depths for different open cup densities.

		Gassed blend containing 60% emulsion – Density g/cm ³												
	Avg.		Avg.		Avg.		Avg.		Avg.		Avg.		Avg.	
Depth (m)	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe
Open Cup	0.90	0.90	0.95	0.95	1.00	1.00	1.05	1.05	1.10	1.10	1.15	1.15	1.20	1.20
1	0.92	0.94	0.97	0.99	1.02	1.04	1.07	1.09	1.12	1.13	1.16	1.18	1.21	1.22
2	0.94	0.98	0.99	1.03	1.04	1.07	1.08	1.12	1.13	1.16	1.18	1.20	1.22	1.25
3	0.96	1.02	1.01	1.06	1.05	1.10	1.10	1.14	1.14	1.18	1.19	1.22	1.23	1.26
4	0.98	1.05	1.02	1.09	1.07	1.13	1.11	1.17	1.16	1.20	1.20	1.24	1.24	1.28
5	0.99	1.07	1.04	1.11	1.08	1.15	1.12	1.19	1.17	1.22	1.21	1.26	1.25	1.29
6	1.01	1.10	1.05	1.13	1.09	1.17	1.14	1.20	1.18	1.24	1.22	1.27	1.26	1.30
7	1.02	1.12	1.06	1.15	1.11	1.19	1.15	1.22	1.19	1.25	1.23	1.28	1.26	1.31
8	1.04	1.14	1.08	1.17	1.12	1.20	1.16	1.23	1.19	1.26	1.23	1.29	1.27	1.32
9	1.05	1.16	1.09	1.19	1.13	1.22	1.17	1.25	1.20	1.27	1.24	1.30	1.28	1.33
10	1.06	1.17	1.10	1.20	1.14	1.23	1.17	1.26	1.21	1.28	1.25	1.31	1.28	1.33
11	1.07	1.19	1.11	1.21	1.14	1.24	1.18	1.27	1.22	1.29	1.25	1.32	1.29	1.34
12	1.08	1.20	1.12	1.23	1.15	1.25	1.19	1.28	1.22	1.30	1.26	1.32	1.29	1.34
13	1.09	1.21	1.13	1.24	1.16	1.26	1.20	1.28	1.23	1.31	1.26	1.33	1.29	1.35
14	1.10	1.22	1.13	1.25	1.17	1.27	1.20	1.29	1.23	1.31	1.27	1.33	1.30	1.35
15	1.11	1.23	1.14	1.25	1.17	1.28	1.21	1.30	1.24	1.32	1.27	1.34	1.30	1.36
16	1.11	1.24	1.15	1.26	1.18	1.28	1.21	1.30	1.24	1.32	1.28	1.34	1.31	1.36
17	1.12	1.25	1.15	1.27	1.19	1.29	1.22	1.31	1.25	1.33	1.28	1.35	1.31	1.36
18	1.13	1.26	1.16	1.28	1.19	1.30	1.22	1.31	1.25	1.33	1.28	1.35	1.31	1.37
19	1.14	1.26	1.17	1.28	1.20	1.30	1.23	1.32	1.26	1.34	1.29	1.35	1.31	1.37
20	1.14	1.27	1.17	1.29	1.20	1.31	1.23	1.32	1.26	1.34	1.29	1.36	1.32	1.37
22	1.15	1.28	1.18	1.30	1.21	1.32	1.24	1.33	1.27	1.35	1.29	1.36	1.32	1.38
24	1.15	1.29	1.18	1.31	1.21	1.32	1.24	1.34	1.27	1.35	1.30	1.37	1.32	1.38
26	1.16	1.30	1.19	1.32	1.22	1.33	1.25	1.35	1.27	1.36	1.30	1.37	1.32	1.38
28	1.17	1.31	1.20	1.32	1.22	1.34	1.25	1.35	1.28	1.36	1.30	1.38	1.33	1.39
30	1.17	1.32	1.20	1.33	1.23	1.34	1.25	1.36	1.28	1.37	1.31	1.38	1.33	1.39
32	1.18	1.32	1.21	1.34	1.23	1.35	1.26	1.36	1.28	1.37	1.31	1.38	1.33	1.39
34	1.18	1.33	1.21	1.34	1.24	1.35	1.26	1.36	1.29	1.37	1.31	1.39		
36	1.19	1.34	1.22	1.35	1.24	1.36	1.27	1.37	1.29	1.38	1.31	1.39		
38	1.19	1.34	1.22	1.35	1.24	1.36	1.27	1.37	1.29	1.38	1.32	1.39		
40	1.20	1.35	1.22	1.36	1.25	1.36	1.27	1.37	1.30	1.38	1.32	1.39		
45	1.20	1.35	1.23	1.36	1.25	1.37	1.28	1.38	1.30	1.38	1.32	1.39		
50	1.21	1.35	1.23	1.36	1.26	1.37	1.28	1.38	1.30	1.39	1.32	1.39		
55	1.21	1.35	1.24	1.36	1.26	1.37	1.28	1.38	1.30	1.39	1.33	1.39		
60	1.22	1.35	1.24	1.36	1.26	1.37	1.28	1.38	1.31	1.39	1.33	1.39		

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry hole conditions. In wet hole conditions, the value selected from the left hand column must be the sum of the product column and the height of the water column in the hole. If the length of the product and water column exceeds the depth of the hole then the value selected from the left hand column must be the hole depth.
- This table applies for TITAN 3000, TITAN 5000 and TITAN 9000 Matrix blends with an emulsion content of 60% w/w ONLY, i.e. T9060G.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in vertical and near vertical blastholes and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (a Toe density of 1.38g/cm³ in the 1.10 g/cm³ open cup density column). This indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density of 1.10g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the shaded column (an Avg. In-Hole density of 1.30g/cm³ in the 1.10 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth. e.g. a 25m deep hole should be rounded to 26m and corresponding densities applied.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU operator to achieve the associated open cup density.
- The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is
 necessary to allow at least this time to elapse following completion of loading and before stemming
 the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.
- The low density explosive grade ammonium nitrate used in the model was assigned a bulk density of 0.77 g/cm³ and a particle density of 1.58 g/cm³.

Gassing density for TITAN[®] blends

Density of gas sensitised blends containing 70% TITAN 3000, TITAN 5000 or TITAN 9000 in an explosive column at different depths for different open cup densities.

				Gasse	d blend o	contai	ning 70%	emul	sion – D	ensity	g/cm ³			
	Avg.		Avg.		Avg.		Avg.		Avg.		Avg.		Avg.	
Depth (m)	In-Hole	Toe	In-Hole		In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe	In-Hole	Toe
Open Cup	0.90	0.90	0.95	0.95	1.00	1.00	1.05	1.05	1.10	1.10	1.15	1.15	1.20	1.20
1	0.92	0.94	0.97	0.99	1.02	1.04	1.07	1.08	1.12	1.13	1.16	1.18	1.21	1.22
2	0.94	0.98	0.99	1.02	1.04	1.07	1.08	1.11	1.13	1.16	1.18	1.20	1.22	1.24
3	0.96	1.01	1.00	1.05	1.05	1.10	1.10	1.14	1.14	1.18	1.19	1.22	1.23	1.26
4	0.97	1.04	1.02	1.08	1.07	1.12	1.11	1.16	1.15	1.20	1.20	1.23	1.24	1.27
5	0.99	1.07	1.03	1.11	1.08	1.14	1.12	1.18	1.16	1.21	1.20	1.25	1.25	1.28
6	1.00	1.09	1.05	1.13	1.09	1.16	1.13	1.20	1.17	1.23	1.21	1.26	1.25	1.29
7	1.02	1.11	1.06	1.15	1.10	1.18	1.14	1.21	1.18	1.24	1.22	1.27	1.26	1.30
8	1.03	1.13	1.07	1.16	1.11	1.19	1.15	1.22	1.19	1.25	1.23	1.28	1.26	1.31
9	1.04	1.15	1.08	1.18	1.12	1.21	1.16	1.24	1.20	1.26	1.23	1.29	1.27	1.32
10	1.05	1.16	1.09	1.19	1.13	1.22	1.17	1.25	1.20	1.27	1.24	1.30	1.27	1.32
11	1.06	1.17	1.10	1.20	1.14	1.23	1.17	1.25	1.21	1.28	1.24	1.30	1.28	1.33
12	1.07	1.19	1.11	1.21	1.15	1.24	1.18	1.26	1.22	1.29	1.25	1.31	1.28	1.33
13	1.08	1.20	1.12	1.22	1.15	1.25	1.19	1.27	1.22	1.29	1.25	1.31	1.29	1.34
14	1.09	1.21	1.13	1.23	1.16	1.26	1.19	1.28	1.23	1.30	1.26	1.32	1.29	1.34
15	1.10	1.22	1.13	1.24	1.17	1.26	1.20	1.28	1.23	1.30	1.26	1.32	1.29	1.34
16	1.11	1.23	1.14	1.25	1.17	1.27	1.20	1.29	1.24	1.31	1.27	1.33	1.30	1.35
17	1.11	1.24	1.15	1.26	1.18	1.28	1.21	1.30	1.24	1.31	1.27	1.33	1.30	1.35
18	1.12	1.24	1.15	1.26	1.18	1.28	1.21	1.30	1.24	1.32	1.27	1.34	1.30	1.35
19	1.13	1.25	1.16	1.27	1.19	1.29	1.22	1.31	1.25	1.32	1.28	1.34	1.30	1.35
20	1.13	1.26	1.16	1.27	1.19	1.29	1.22	1.31	1.25	1.33	1.28	1.34	1.31	1.36
22	1.14	1.27	1.17	1.29	1.20	1.30	1.23	1.32	1.26	1.33	1.28	1.35	1.31	1.36
24	1.14	1.28	1.17	1.29	1.20	1.31	1.23	1.32	1.26	1.34	1.29	1.35	1.31	1.37
26	1.15	1.29	1.18	1.30	1.21	1.32	1.24	1.33	1.26	1.34	1.29	1.36	1.31	1.37
28	1.16	1.29	1.18	1.31	1.21	1.32	1.24	1.34	1.27	1.35	1.29	1.36	1.32	1.37
30	1.16	1.30	1.19	1.32	1.22	1.33	1.24	1.34	1.27	1.35	1.29	1.36	1.32	1.37
32	1.17	1.31	1.19	1.32	1.22	1.33	1.25	1.34	1.27	1.36	1.30	1.37		
34	1.17	1.31	1.20	1.33	1.23	1.34	1.25	1.35	1.28	1.36	1.30	1.37		
36	1.18	1.32	1.20	1.33	1.23	1.34	1.25	1.35	1.28	1.36	1.30	1.37		
38	1.18	1.32	1.21	1.33	1.23	1.34	1.26	1.35	1.28	1.36	1.30	1.37		
40	1.19	1.33	1.21	1.34	1.24	1.35	1.26	1.36	1.28	1.37				
45	1.19	1.33	1.22	1.34	1.24	1.35	1.26	1.36	1.29	1.37				
50	1.20	1.33	1.22	1.34	1.24	1.35	1.27	1.36	1.29	1.37				
55	1.20	1.34	1.22	1.34	1.25	1.35	1.27	1.36	1.29	1.37				
60	1.20	1.34	1.23	1.35	1.25	1.35	1.27	1.36	1.29	1.37				

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry hole conditions. In wet hole conditions, the value selected from the left hand column must be the sum of the product column and the height of the water column in the hole. If the length of the product and water column exceeds the depth of the hole then the value selected from the left hand column must be the hole depth.
- This table applies for TITAN 3000, TITAN 5000 and TITAN 9000 Matrix blends with an emulsion content of 70% w/w ONLY, i.e. T9070G.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in vertical and near vertical blastholes and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (a Toe density of 1.37g/cm³ in the 1.10 g/cm³ open cup density column). This indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density at 1.10g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 40m (for example), find 40m in the Depth column. Moving to the right, read off the density in the shaded column (an Avg. In-Hole density of 1.28g/cm³ in the 1.10 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth. e.g. a 25m deep hole should be rounded to 26m and corresponding densities applied.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU operator to achieve the associated open cup density.
- The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is
 necessary to allow at least this time to elapse following completion of loading and before stemming
 the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.
- The low density explosive grade ammonium nitrate used in the model was assigned a bulk density of 0.77 g/cm³ and a particle density of 1.58 g/cm³.

Gassing density for TITAN[®] blends

Density of gas sensitised TITAN 9000xero[®] in an explosive column at different depths for different open cup densities.

				TI	TAN 9000	Dxero	gassed	blend	– Densi	ty g/c	m ³			
	Avg		Avg		Avg		Avg		Avg		Avg		Avg	
Depth (m)	in-hole	Toe	in-hole	Toe	in-hole	Toe	in-hole	Toe	in-hole	Toe	in-hole	Toe	in-hole	Toe
Open cup	0.90	0.90	0.95	0.95	1.00	1.00	1.05	1.05	1.10	1.10	1.15	1.15	1.20	1.20
1	0.92	0.94	0.97	0.98	1.02	1.03	1.06	1.08	1.11	1.12	1.16	1.17	1.21	1.22
2	0.93	0.97	0.98	1.01	1.03	1.06	1.08	1.10	1.12	1.14	1.17	1.19	1.21	1.23
3	0.95	1.00	1.00	1.04	1.04	1.08	1.09	1.12	1.13	1.16	1.18	1.20	1.22	1.24
4	0.96	1.02	1.01	1.06	1.05	1.10	1.10	1.14	1.14	1.18	1.18	1.21	1.23	1.25
5	0.98	1.04	1.02	1.08	1.06	1.12	1.11	1.15	1.15	1.19	1.19	1.22	1.23	1.26
6	0.99	1.06	1.03	1.10	1.07	1.13	1.12	1.17	1.16	1.20	1.20	1.23	1.24	1.26
7	1.00	1.08	1.04	1.12	1.08	1.15	1.12	1.18	1.16	1.21	1.20	1.24	1.24	1.27
8	1.01	1.10	1.05	1.13	1.09	1.16	1.13	1.19	1.17	1.22	1.21	1.25	1.24	1.27
9	1.02	1.11	1.06	1.14	1.10	1.17	1.14	1.20	1.18	1.23	1.21	1.25	1.25	1.28
10	1.03	1.12	1.07	1.15	1.11	1.18	1.14	1.21	1.18	1.23	1.22	1.26	1.25	1.28
11	1.04	1.14	1.08	1.16	1.11	1.19	1.15	1.22	1.19	1.24	1.22	1.26		
12	1.05	1.15	1.09	1.17	1.12	1.20	1.16	1.22	1.19	1.25	1.22	1.27		
13	1.06	1.16	1.09	1.18	1.13	1.21	1.16	1.23	1.19	1.25	1.23	1.27		
14	1.06	1.17	1.10	1.19	1.13	1.21	1.17	1.23	1.20	1.26	1.23	1.28		
15	1.07	1.17	1.10	1.20	1.14	1.22	1.17	1.24	1.20	1.26	1.23	1.28		
16	1.08	1.18	1.11	1.20	1.14	1.22	1.17	1.24	1.21	1.26	1.24	1.28		
17	1.08	1.19	1.12	1.21	1.15	1.23	1.18	1.25	1.21	1.27	1.24	1.28		
18	1.09	1.19	1.12	1.21	1.15	1.23	1.18	1.25	1.21	1.27				
19	1.09	1.20	1.13	1.22	1.16	1.24	1.19	1.26	1.22	1.27				
20	1.10	1.21	1.13	1.22	1.16	1.24	1.19	1.26	1.22	1.28				
22	1.11	1.22	1.14	1.23	1.16	1.25	1.19	1.27	1.22	1.28				
24	1.11	1.23	1.14	1.24	1.17	1.26	1.20	1.27						
26	1.12	1.23	1.14	1.25	1.17	1.26	1.20	1.28						
28	1.12	1.24	1.15	1.25	1.18	1.27	1.20	1.28						
30	1.13	1.25	1.15	1.26	1.18	1.27	1.21	1.28						
32	1.13	1.25	1.16	1.26	1.18	1.28								
34	1.13	1.26	1.16	1.27	1.19	1.28								
36	1.14	1.26	1.17	1.27	1.19	1.28								
38	1.14	1.27	1.17	1.28										
40	1.15	1.27	1.17	1.28										
45	1.15	1.27	1.18	1.28										
50	1.15	1.27	1.18	1.28										
55	1.16	1.27	1.18	1.28										
60	1.16	1.28												

See below for use of table

USE OF TABLE

- The left hand column in this table (Depth) indicates the height of the product column under dry hole conditions. In wet hole conditions, the value selected from the left hand column must be the sum of the product column plus the height of the water column in the hole. If the length of the product and water column exceeds the depth of the hole then the value selected from the left hand column must be the hole depth.
- 2. This table applies for TITAN 9000xero Matrix blend with an emulsion content of 80% w/w ONLY.
- 3. Emulsion explosives behave as liquids when subjected to the gravitational stress in a vertical blasthole, and a pressure gradient in the explosive will be established. The higher the explosive column in the blasthole, the higher the internal pressure at the bottom of the column, and the larger the quantity of gassing chemicals that need to be added to provide sensitisation.
- 4. The open cup density is a measure of the level of sensitisation of the product. It is necessary to choose an open cup density to ensure that the density of the explosive at the bottom of the blasthole is less than the critical density. Inappropriate sensitisation may lead to poor detonation, fragmentation and generation of excessive post blast fume. Blacked out areas indicate where critical density is reached or exceeded.
- 5. To determine the required open cup density for an explosive column of 30m (for example), find 30m in the Depth column. Moving to the right, read off the density in the unshaded column under the required open cup density (e.g. a Toe density of 1.28g/cm³ in the 1.05 g/cm³ open cup density column). In this example, this indicates that sufficient gassing chemicals should be added to the gassed explosive blend during delivery so that an open cup density of 1.05g/cm³ is achieved. This level of gassing chemicals will ensure that the density at the bottom of the column will be below the critical density, and the column will detonate at full order upon initiation.
- 6. To determine the approximate average in-hole density in a column of 30m (for example), find 30m in the Depth column. Moving to the right, read off the density in the shaded column (e.g. an Avg. In-Hole density of 1.21g/cm³ in the 1.05 g/cm³ open cup density column). For depths that are not listed, Dyno Nobel recommends rounding up to the next highest depth. e.g. a 25m deep hole should be rounded to 25m and corresponding densities applied.
- Blast design should be based on average in-hole density whilst blasthole loading requires the MPU
 operator to achieve the associated open cup density.
- 8. The gassing reaction takes 30-40 minutes to achieve the desired open cup density at 20°C. It is necessary to allow at least this time to elapse following completion of loading and before stemming the charged blasthole. A longer period should be allowed at lower temperatures.
- The density values shown were calculated using a laboratory mathematical model that was validated using a specially designed fit-for-purpose pressure-volume apparatus.

Conversion table

	ultiplied b	by 🕨 Converts to
Length		
metres (m)	3.280	feet (ft)
	39.370	inches (in)
inches (in)	25.400	millimetres (mm)
kilometres (km)	0.621	miles
Mass		
kilogram (kg)	2.20	lb
metric tonne (t)	1.10	short tons
ounce		
Avoirdupois (oz)	28.35	grams (g)
ounce Troy (oz)	31.10	grams (g)
grains	0.06	grams (g)
Energy		
joule		
Joule	0.24	calorie
Jouie	0.24 0.74	calorie ft-lb
calorie		
	0.74	ft-lb
calorie	0.74 3.09	ft-lb
calorie kilowatt	0.74 3.09 1.34	ft-lb
calorie kilowatt Volume	0.74 3.09 1.34	ft-lb ft-lb horsepower
calorie kilowatt Volume cubic centimetres	0.74 3.09 1.34 6 0.06	ft-lb ft-lb horsepower
calorie kilowatt Volume cubic centimetres (cm ³ or cc)	0.74 3.09 1.34 6 0.06	ft-lb ft-lb horsepower in ³
calorie kilowatt Volume cubic centimetres (cm³ or cc) cubic metres (m³)	0.74 3.09 1.34 6 0.06 1.31	ft-lb ft-lb horsepower in ³ yd ³
calorie kilowatt Volume cubic centimetres (cm ³ or cc) cubic metres (m ³) cubic feet (ft ³)	0.74 3.09 1.34 5 0.06 1.31 0.03	ft-lb ft-lb horsepower in ³ yd ³ m ³

This unit 🕨 I	Aultiplied by	Converts to							
Density									
lbs / ft ³	16.02	kg / m³							
gm / cm³	62.43	lbs / ft ³							
Powder Factor									
kg / m³	1.69	lb / yd³							
Speed									
m / sec	3.28	ft / sec							
in / sec	25.4	mm / sec							
km / hour	0.62	miles / hour							
Pressure									
psi	6.89	kPa							
atmosphere (atr	n) 14.70	psi							
bar	14.50	psi							
bar	100	kPa							
Temperatur	e								
fahrenheit -32	0.56	centigrade							
centigrade + 17	.78 1.8	fahrenheit							
Area									
Cm ²	0.16	in²							
m ²	1550.00	in²							
ft²	0.09	m²							
Converts to ┥	Divided by	┥ This unit							

Properties of typical rock types

Material

	Solid Density (t/m³)	Unconfined Compressive Strength (MPa)	Young's Modulus (GPa)	Poisson's Ratio
Basalt	3.00	78 – 412	20 - 100	0.14 - 0.25
Bauxite	2.05			
Clay – dense, wet	1.70			
Coal, Anthracite	1.60	8 - 50		
Coal, Bituminous	1.36			
Dolerite	2.80	290 - 500		
Dolomite	2.96	15 – 118	20 - 84	0.1 – 0.2
Earth, moist	1.80			
Gneiss	2.88	78 – 240	25 - 60	0.1 - 0.19
Granite	2.72	100 – 275	25 - 70	0.15 - 0.34
Gypsum	2.80			
Iron ore	4.89			
Limestone	2.64	10 – 245	10 - 80	0.1 - 0.23
Limonite	3.76			
Magnetite	5.05			
Marble	2.48	50 - 200	60 - 90	0.2 - 0.35
Mica-Schist	2.70			
Porphory	2.56			
Quartzite	2.50	85 - 350	26 - 100	0.15 – 0.2
Sandstone	2.40	50 - 160	5 - 86	0.1 – 0.3
Shale	2.58	20 - 150	8 - 30	0.1 – 0.3
Silica Sand	2.56			
Siltstone	2.25			
Slate	2.72	98 - 196	30 - 90	0.1 – 0.44
Talc	2.64			

© Dyno Nobel Asia Pacific Pty Limited 2020. Reproduction without permission is strictly prohibited.

Perimeter control

Perimeter blasting is a technique to reduce the overbreak/backbreak on a blast. It usually utilises decoupled charges in closely spaced blastholes.

The following formula can be used to estimate the centre to centre distances of cartridged product for pre-splitting.

 $PF = \frac{L \times S}{0.5}$

- PF = Required powder factor (usually 0.3 to 0.6 kg/m²)
- L = Length of charged hole
- S = Spacing between holes

 $D = \frac{L \times Q_L}{B \times S \times PF}$

- D = Centre centre distance between cartridges (mm)
- QL = Charge density of the explosive, in kg/m
- B = Burden

Airblast

An airblast is an airborne shock wave that results from the detonation of explosives. The severity of an airblast is dependent on explosive charge, distance, and especially the explosives confinement.

$$\mathbf{P} = \mathbf{K} \left[\frac{\mathbf{R}}{\mathbf{Q}^{0.33}} \right]^{-1.2}$$

Where

- P = pressure (kPa)
- K = state of confinement
- Q = maximum instantaneous charge (kg)
- R = distance from charge (m)

Typical K factors

Unconfined	185
Fully confined	3.3

Expected damage

kPa 0.3 Windows rattle 0.7 1% of windows break

7 Most windows break, plaster cracks

Sound level calculation

$$Lp(dB) = 20 \log \left[\frac{P}{20 \times 10^{-9}}\right]$$

Minimum levels quoted

Human discomfort 120dB(li

Onset of structure damage 130dB(lin)

or historic buildings where no specific limit exists

Please reference AS 2187.2 - 2006 for further information

Ground vibration

When an explosive is detonated in a blasthole, a pressure wave is generated in the surrounding rock. As this pressure wave moves from the blasthole it forms seismic waves by displacing particles. The particle movement is measured to determine the magnitude of the blast vibration. Maximum particle vibration can be estimated using the following formula.

$$\mathbf{V} = \mathbf{K} \begin{bmatrix} \mathbf{R} \\ \mathbf{Q}^{0.5} \end{bmatrix}^{\mathrm{B}}$$

Where

- V = peak particle velocity (mm/s)
- K = site and rock factor constant
- Q = maximum instantaneous charge (kg)
- B = constant related to the rock and site (usually -1.6)
- R = distance from charge (m)

Typical K factors

Free face - hard or highly structured rock	500
Free face average rock	1140
Heavily confined	5000

Recommended maximum Peak Particle Velocities (AS 2187.2 - 1993)

Housing and low rise residential buildings,	10 mm/s
Commercial buildings not included below	
Commercial and industrial buildings or structures of reinforced concrete or steel constructions	25 mm/s
For high rise, hospitals, long floor spans, dams or historic buildings where no specified limit exists	5 mm/s


Please reference AS 2187.2 - 2006 for further information

Expected damage

PPV (mm/s)

13	Lower limit for damage to plaster walls
19	Lower limit for dry wall structures
70	Minor damage
140	>50% chance of minor damage to structures
190	50% chance of major damage

Underground blast design



Shoulder hole	These refer to those holes immediately below the back perimeter holes.
Burncut	The burncut consists of a group of blastholes arranged in a regular pattern around one or more uncharged relief holes. The first firing blasthole breaks both into the void offered by the uncharged relief holes and towards the free face provided by the tunnel face.
Easer	Hole adjacent to cut area.
Lifters	The blastholes along the bottom of the developed round. Proper performance of the lifters are essential in achieving good floor control.
Perimeter blastholes	Perimeter blastholes are those which form the boundary of the tunnel. Explosive loading densities in these blastholes are generally lower than those in the remainder of the blast, as their prime requirement is to minimise back-breakage and provide a good contour.

© Dyno Nobel Asia Pacific Pty Limited 2020. Reproduction without permission is strictly prohibited.

Underground blast design

Design of cut

The following formulae are used for the geometric design of the cut area: For multiple reamer holes: $\emptyset = d\sqrt{n}$

Where: d = diameter of empty reamer holes; n = number of reamer holes

The cut:

2nd

1st squ	Jare	: a	= 1.5ø					
$W_1 = a \sqrt{2}$								
ø mm	=	76	89	102	127	154		
a mm	=	110	130	150	190	230		
W₁ mm	=	150	180	210	270	320		

square:	$B_1 = W_1$
	$C-C = 1.5W_1$

$$N_2 = 1.5W_1 \sqrt{2}$$

ø mm	=	76	89	102	127	154
W 1	=	150	180	210	270	320
C-C	=	225	270	310	400	480
W ₂ mm	=	320	380	440	560	670

3rd square:
$$B_2 = W_2$$

 $C-C = 1.5W_2$
 $W_3 = 1.5W_2 \ \sqrt{2}$

ø mm	=	76	89	102	127	154
W ₂ mm	=	320	380	440	560	670
C-C	=	480	570	660	840	1000
W₃mm	=	670	800	930	1180	1400

4th square:
$$B_3 = W_3$$


C-C = 1.5W₃

$$W_4=1.5W_3\sqrt{2}$$

ø mm	=	76	89	102	127	
W₃mm	=	670	800	930	1180	
C-C	=	1000	1200	1400	1750	
W₃mm	=	1400	1700	1980	2400	







32


Design of lifter and easer holes

When the cut holes have been calculated, the rest of the development round may be calculated.

The round is divided into:

- lifter holes
- side holes
- back holes
- easer holes with breakage upwards and horizontally
- easer holes with breakage downwards

To calculate burdens (B) and charges for the different parts of the round the following graph may be used as a basis.



Bulk products

TITAN [®] Emulsion Product	% ANFO (%wt)	Density (g/cm ³)	Energy Range (MJ/kg)	Recommended Min. Hole Diameter
TITAN 2000G (Gassed)	0	0.90 - 1.25*	2.5	102 mm
TITAN 2070G (Gassed)	30	0.90 - 1.25*	2.8	102 mm
TITAN 2060G (Gassed)	40	0.90 - 1.25*	3.0	102 mm
TITAN 2050G (Gassed)	50	1.10 - 1.20*	3.1	102 mm
TITAN 2050 (Heavy ANFO)	50	1.30#	3.1	200 mm
TITAN 2040 (Heavy ANFO)	60	1.25#	3.2	127 mm
TITAN 2030 (Heavy ANFO)	70	1.10#	3.3	102 mm
TITAN 2020 (Heavy ANFO)	80	0.97#	3.4	102 mm
TITAN 3000G (Gassed)	0	0.90 - 1.25*	2.7	76 mm
TITAN 3070G (Gassed)	30	0.90 - 1.25*	3.0	76 mm
TITAN 3060G (Gassed)	40	0.90 - 1.25*	3.1	89 mm
TITAN 3050G (Gassed)	50	1.10 - 1.20*	3.2	102 mm
TITAN 3050 (Heavy ANFO)	50	1.32#	3.2	200 mm
TITAN 3040 (Heavy ANFO)	60	1.26#	3.3	127 mm
TITAN 3030 (Heavy ANFO)	70	1.10#	3.4	102 mm
TITAN 3020 (Heavy ANFO)	80	0.98#	3.5	102 mm
TITAN 5000G (Gassed)	0	0.90 - 1.25*	2.5	102 mm
TITAN 5070G (Gassed)	30	0.90 - 1.25*	2.8	102 mm
TITAN 5060G (Gassed)	40	0.90 - 1.25*	3.0	102 mm
TITAN 5050G (Gassed)	50	1.10 - 1.20*	3.1	102 mm
TITAN 5050 (Heavy ANFO)	50	1.31#	3.1	200 mm
TITAN 5040 (Heavy ANFO)	60	1.26#	3.2	127 mm
TITAN 5030 (Heavy ANFO)	70	1.10#	3.3	102 mm
TITAN 5020 (Heavy ANFO)	80	0.98#	3-4	102 mm
TITAN 7000 (Gassed)	0	0.80 - 1.25*	2.9	35 mm
TITAN 7000i (Gassed)	0	0.80 - 1.25*	2.9	35 mm
TITAN 7000sx (Gassed)	0	0.80 - 1.25*	2.8	38 mm
FITAN 9000G (Gassed)	0	0.90 - 1.25*	2.7	76 mm
TITAN 9070G (Gassed)	30	0.90 - 1.25*	3.0	76 mm
TITAN 9060G (Gassed)	40	0.90 - 1.25*	3.1	89 mm
TITAN 9050G (Gassed)	50	1.10 - 1.20*	3.2	102 mm
TITAN 9050 (Heavy ANFO)	50	1.32#	3.2	200 mm
TITAN 9040 (Heavy ANFO)	60	1.26#	3.3	127 mm
TITAN 9030 (Heavy ANFO)	70	1.10#	3.4	102 mm
TITAN 9020 (Heavy ANFO)	80	0.98#	3.5	102 mm
TITAN 9000xero® (Gassed)	0	0.90 - 1.20*	2.0	150 mm

* Nominal open cup densities. In hole gassed product densities are dependent on the hole depth.

Nominal open cup densities. In field densities may vary due to the AN prill density and/or sampling techniques.

Bulk products

How to select the right TITAN° matrix product for your needs

The table below is a guide to choosing the right product for the blasthole condition and desired performance. Please consult your Dyno Nobel representative for more further details.

Emulsion Co	intent % w /w		10	20	30	40	50	60	70	80	90	100
Dewate	Dry 1	Use										
	Delivery Meth	iod ²	Α	Α	А	А	A	A / P	A/P	A / P	A / P	A / P
	Dewatered ³	Use		No								
	Delivery Meth	iod	-	-	-	Α	A	A / P	A/P	A/P	A / P	A / P
Conditions	Wet 4	Use			No							
	Delivery Meth	iod	-	-	-	-	-	Р	Р	Р	Р	Р
	Dynamic 5	Use	N			lo						
	Delivery Meth	od	-	-	-	-	-	-	Р	Р	Р	Р
Sensitisation Required			N	o		Note 6						

Product selection guide - blasthole condition

NOTES:

- 1. Dry hole is defined as a blast hole containing no water including no wet walls.
- 2. A = Auger, P = Pumped.
- 3. A dewatered hole is defined as a wet hole where water has been removed and is not recharging.
- 4. A wet hole is defined as a blast hole containing static water or has a recharge rate of <1m in 30 minutes.
- Dynamic water is defined as a recharge rate of >1m in 30 minutes. If the level of dynamic water is such that product damage is suspected or observed, the suggested recommended sleep time should be reduced.
- 6. This product has reduced sensitivity and sensitisation is recommended for all hole. Please consult your Dyno Nobel representative to check which delivery options are available at your location.
- 7. The TITAN Matrix Blend Gassing Table should be used to determine the appropriate open cup density for the hole depth.

ANFO



Typical densit	у	Theoretica	Recomm		
g/cm ³		(MJ/kg)	RWS	RBS	min hole (mm)
Poured	0.8 - 0.85	3.7	100	100	75
Blow loaded	0.85 - 0.95	3.7	100	116	25

BLAST HI-T™



Typical densit	у	Theoretica	Theoretical energy comparison					
g/cm ³		(MJ/kg)	RWS	RBS	min hole (mm)			
Poured	0.8 - 0.85	3.7	100	100	75			
Blow loaded	0.85 - 0.95	3.7	100	116	25			

SANFOLD®



	Typical	Typical	Theoretical	Recomm	Recomm
	density	density	energy	min hole	min hole
	(Poured)	(Blow loaded)	comparison	(Poured)	(Blow loaded)
	g/cm ³	g/cm ³	(MJ/kg)	(mm)	(mm)
SANFOLD® 50	0.55	0.67	3.51	50	-

Packaged products

DynoSplit® Pro



Density (g/cm ³) ¹	Velocity of Detonation (m/s) ²	Maximum Temperature (°C)
1.15 – 1.21	Min 6500	55

1 Values are indicative average densities only, determined under laboratory conditions. Observed may differ or vary under field conditions. Normal in hole density only.

2 VOD of product is dependent on VOD of detonating cord.

Packaging

Diameter (mm)	Charge (kg/cart)	Quantity (m/case)	Case Weight (kg)
26	0.225	27.0	17
32	0.355	20.0	17

DynoSplit[®] Pro RiGHT[®]

split D	ynosplit	DynoSplit	DynoSp	olit D
EXPLOSIVE	OSIVE DANGE	DANGEN EXPLOSIVE	ANDEN EVEN	INISOTAXE &
DALACI J	ildsony a	A CARDON PLANTING	ahous was	21 02
	i Dyne	Split Dia	spin	DANGER EXPL

Density (g/cm³) 1

Velocity of Detonation (m/s) ²

Maximum Temperature (°C) and sleep time ³

1.08 – 1.12	Min 6500	100°C for 8 hours

1 Values are indicative average densities only, determined under laboratory conditions. Observed densities may differ or vary under field conditions. Nominal in hole density only.

2 VOD of product is dependent on VOD of detonating cord.

3 In hot ground. In reactive ground the maximum sleep time available will vary according to the reactivity of the ground and temperature of use. Please consult your Dyno Nobel customer representative in order for the required testing to ascertain the available sleep to be performed. In hole temperature monitoring, and testing of representative rock samples for the specific site will need to be performed to confirm the specific sleep time able to be achieved for the specific customer site.

Packaging

Diameter (mm)	Charge (kg/cart)	Quantity (m/case)	Case Weight (kg)
26	0.225	27.0	17
32	0.355	30.0	25

© Dyno Nobel Asia Pacific Pty Limited 2020. Reproduction without permission is strictly prohibited.

Packaged products

Z-BAR®



Diameter	Charge	VoD	Maximum case
(mm)	(kg/m)		weight (kg)
29	0.50	6500	25

Packaging

Length	Quantity per case	Length per case
3.0 m	12	36
3.5 m	10	35

POWERMITE® PRO



Typical density	Theoretical energy comparison			VoD
(g/cm ³)	Energy (MJ/kg)	RWS	RBS	(m/s)
1.16 – 1.23	<= 32mm 2.78	121	183	3400
	>= 45mm 2.72			

Quantity per 25kg case	Average cartridge weight (g)	Case weight kg
215	105	25
60	390	25
135	185	25
34	736	25
33	758	25
21	1190	25
15	1670	25
	per 25kg case 215 60 135 34 33 21	per 25kg case weight (g) 215 105 60 390 135 185 34 736 33 758 21 1190

POWERMITE THERMO®



Nominal Density (g/cm³)	Energy (MJ/kg) ¹	Relative Weight Strength (%) ¹	Relative Bulk Strength (%) ¹	VOD (m/s) ²	Sensitivity	Detonation Pressure ³
1.15 – 1.21	3.60	96	138	5400	8g/m det cord	8.6

1 All Dyno Nobel energy values are calculated using a proprietary Dyno Nobel thermodynamic code. Other programs may give different values. The values given are relative to ANFO at 0.82 g/cm³.

2 VOD is dependent on product density, diameter, the degree of confinement and other factors.

3 Calculated using an ideal thermodynamic code.

Packaging	Cart Weight (kg)	Chubs per case
540 x 336 x 240mm	25 kg	40

Initiation systems – downhole

NONEL[®] MS Series



NONEL MS Series



NONEL MS HD Series

Delay period (ms)	J-Hook colour	Nominal firing time (ms)	Time between delays (ms)
1	Red	25	25
2	Blue	50	25
3	Brown	75	25
4	Orange	100	25
5	Agua	125	25
6	Gold	150	25
7	Lime Green	175	25
8	Pink	200	25
9	Black	225	25
10	Purple	250	25
11	Light Blue	275	25
12	Light Green	300	25
13	Mauve	325	25
14	Mustard	350	25
15	Crimson	375	25
16	Yellow	400	25
17	Dark Blue	425	25
18	Green	450	25
19	Orange	475	25
20	White	500	25
21	Dark Red	550	50
22	Grey	600	50
23	Black	650	50
24	Dark Brown	700	50
25	Red	750	50
26	Blue	800	50
27	Brown	900	100
28	Orange	1000	100
	Packaging	Winding C	onfiguration
Length (m)	Units per case	Standard	Heavy Duty
4.8	180	Figure 80	n/a
6.0	180	Figure 80	Figure 80
7.2	180	Figure 80	Figure 80
9.0	120	Figure 80	Figure 80
12.0	90	Figure 80	Figure 80
15.0	75	Figure 80	Figure 80
18.0	60	Figure 80	Figure 80
24.0	40	n/a	Figure 80
30.0	30	n/a	Spooled
36.0	30	n/a	Spooled
45.0	20	n/o	Speeled

Detonator	# 12 Strength			
Diameter	3.0mm			
Colour	Red			Orange
NONEL® tube:	Standard			Heavy Duty
80.0	30	n/a		Spooled
60.0	30	n/a		Spooled
45.0	30	n/a		Spooled
36.0	30	n/a		Spooled
30.0	30	n/a		Spooled

Initiation systems – downhole

NONEL[®] LP Series



Delay period (ms)	J-Hook colour	Nominal firing time (ms)	Time between delays (ms)
0	White	25	25
1	Red	500	475
2	Blue	800	300
3	Brown	1100	300
4	Orange	1400	300
5	Aqua	1700	300
6	Gold	2000	300
7	Lime Green	2300	300
8	Pink	2700	400
9	Black	3100	400
10	Purple	3500	400
11	Light Blue	3900	400
12	Dark Green	4400	500
13	Mauve	4900	500
14	Mustard	5400	500
15	Crimson	5900	500
16	Yellow	6500	600
17	Dark Blue	7200	700
18	Green	8000	800

Packaging

Length (m)	Units per case	Winding configuration
4.8	180	Figure 80
5.4	180	Figure 80
6.0	180	Figure 80
7.2	180	Figure 80
NONEL tube:	Standard	
Colour	Yellow	
Diameter	3.0mm	
Detonator	# 12 Strength	

NONEL® EZTL Series



Delay period (ms)	Clip colour
9	Purple
17	Yellow
25	Red
42	White
67	Blue
109	Black
150	Dark Green
176	Orange


Packaging

Capacity

Length (m)	Units per case	Winding configuration
4.8	150	Figure 80
6.0	140	Figure 80
7.2	125	Figure 80
9.0	100	Figure 80
12.0	80	Figure 80
15.0	70	Figure 80
18.0	50	Figure 80
24 +	30	Spool
Tube colour	Yellow	
Detonator	Low strength	

6 tubes

NONEL® MS Connector



Delay period (ms)	Clip colour
17	Yellow
25	Red
42	White
67	Blue
109	Black
176	Orange
Packaging Units per case	200
units per case	200
Tube	
Standard	Yellow

NONEL[®] Lead Line 1000

Reel-off initi	ation system (no detonator)	
Length	1000m (two per case)	
VOD	2100m/sec (+/- 300)	
Tube	Standard Yellow / Red	



NONEL® Starter

Pa		

Length (m)	Units per case	Winding configuration
100	16	Spooled
300	4	Spooled
500	4	Spooled
Tube		
Standard	Yellow / Red	



Initiation systems

Cast Boosters



TROJAN SPARTAN



TROJAN TWINPLEX



TROJAN NBU

TROJAN RINGPRIME

	Nominal weight (g)	Diameter (mm)	Length (mm)	Units per case	Priming
TROJAN® SPARTAN 150	150	36	119	48	Detonator sensitive
TROJAN® SPARTAN 400	400	55	119	20	Detonator sensitive
TROJAN® TWINPLEX	450	57	117	18	Detonator sensitive
TROJAN® NBU 400	400	55	119	20	Primacord 5
TROJAN® RINGPRIME®	250	37	175	42	Detonator sensitive

NB: Spiders for RINGPRIME® have 125mm diameter and come in separate 70 unit lots.

Detonating Cords



PRIMACORD 5



PRIMALINE 10





PRIMALINE 8HT

FIRELINE 8/40 RDX

	Core load (g/m)	Diameter (mm)	Minimum strength (kg)	Packaging
PRIMACORD [®] 5	5.3	4	68	2 x 500m rolls
PRIMALINE [®] 10	10	5	68	2 x 350m rolls
PRIMALINE [®] 8HT	8.5	3.2	45	2 x 305m rolls
FIRELINE [®] 8/40 RDX	8.6	4.3	68	2 x 305m rolls

Initiation systems

ELECTRIC SUPER STARTER™

Description	
Delay time (ms)	0
Nominal resistance (ohm)	1.6
Firing current, minimum recommended, (A)	
Series wiring	3 amps AC or 1.5 amps DC
Parallel wiring	1 amp AC or DC per detonator
Series-in-parallel wiring	2 amps AC or DC per series
Leg wires (m)	4.9
Strength (#)	8



The maximum recommended continuous firing current is 10 amps per detonator.

BlastWeb® Electronic Initiation System

BlastWeb Initiation System is a Centralised Blasting System specifically designed for underground blasting operations.

The BlastWeb system can be used to fire SmartShot, DigiShot Plus & DriftShot Starter electronic detonators.

Properties

Temperature Limits	-10°C to +50°C	
Power Supply	110V; 220V; 525V	
Battery	User replaceable/	
	rechargeable 12V 7.2Ah	
	sealed lead acid battery	
Weight	±50Kg	
Dimensions	L = 539-541mm;	
	W = 480-482mm;	
	H = 731-733mm	
External Connectors	SmartKey; USB;	
	(RS-232 & RS-485 for	
	expansion - rear of unit)	
Water Resistance	Splash proof (IP64)	



Initiation systems

EZshot

EZshot® detonator is the newest addition to Dyno Nobel's electronic initiation system portfolio. This exciting technology offers users the benefits of electronic precision and accuracy with the ease of use of NONEL® shock tube in a unique initiation system.

Packaging

Length	6m
Unit/Case	45

Properties

Detonator Shell	Copper
System Operating -20°C to +6	
Temperature (range)	
Delay (ms)	6500
Detonator Strength	#12

DriftShot® Starter Electronic Initiation System

The DriftShot Starter is an electronically initiated detonator intended for the remote firing of detonating cord, generally from the BlastWeb Centralised Blasting System

Packaging

Length	2m
Unit/Case	100 (2 x 1 to 50)

Properties

374N
-20°C to +80°C
#12





DigiShot® Plus.4G

DigiShot Plus.4G electronic initiation system offers accurate timing benefits, quick deployment with robust downline wire and all-weather surface connectors. DigiShot Plus.4G is truly flexible, user friendly and fully programmable.

Properties

Detonator Shell	Copper
Cable Colour	Black with green stripe
Detonator Operating Temperature (range)	-40°C to +80°C
Detonator Strength	#12
Net Explosive Quantity (per 100 units)	0.1kg
Tensile Strength (N)	410 (standard)
	460 (XTM)
Maximum Delay	20,000ms
Maximum Detonators per Blaster	16,000 (synchronised 10 x Bench
	Commanders)
Maximum Surface Wire Length	2.5km

Packaging

Length (m)	Standard Wire Units per case	XTM Wire Units per case
15	60 coils	60 coils
18	52 coils	52 coils
24	40 coils	40 coils
30	32 coils	32 coils
37	24 coils	24 spools
46	20 coils	18 spools
55	16 coils	18 spools
65	16 coils	12 spools
75	16 coils	12 spools



Surface Wire

Description	Length (m)	Units per case
DSPWIRE300M	300	3
DSPWIRE500M	500	2



DYNOSTART™ (DS2)

DYNOSTART is a battery powered electronic blasting machine for initiation of NONEL® tube. Electrical energy is converted into a strong shock wave of high temperature that, when applied inside a NONEL tube by the means of an electrode, initiates the tube. DYNOSTART uses a common 9V battery and a durable electrode. Both battery and electrode are easy to change. The electrode can be removed from the blasting machine at any time to prevent unauthorised usage. DynoStart is designed to require the use of both hands when initiating the blast. This is to avoid unintentional firing of a blast.



DYNOTRACKERTM

The DYNOTRACKER is a device that attaches to the end of a standard charging hose used for loading ANFO. This device allows the use of ANFO as a perimeter charge in tunnelling applications, hereby eliminating the need for more expensive cartridged explosives.



NONEL® Starter Gun

The NONEL Starter Gun is a simple and highly effective hand held blasting machine, robustly constructed from metal alloys and stainless steel. It has an integral safety device and uses Shot Shell Primers No. 20 as primer caps. It is a complete blasting machine, no other equipment being needed to initiate a NONEL tube.



Blasting accessories

STINGER EXPLODER™ 10 Shot

The SB10 is a compact capacitive discharge exploder. The unit is powered by 1.5V AA batteries. A removable magnetic key controls security of the firing mechanism and a push button operates the firing circuit. A ready light illuminates when the firing capacitor is fully charged.



Lo-Stat ANFO Hose

The Lo-Stat ANFO Hose is a conductive thermoplastic tube used for delivery of explosives in underground applications.

Description	ription Product specification	
	20mm hose	25mm hose
Internal Diameter	18.4mm – 19.6 mm	24.6mm – 25.4 mm
Outside Diameter	26.4mm – 27.6 mm	29.8mm - 30.2 mm
Wall Thickness	3.7mm – 4.4 mm	2.3mm – 2.7 mm
Resistance/m metre	15 – 25 KΩ	15 – 25 KΩ
Total Resistance (whole coil)	<1.6 MΩ	<1.6 MΩ
Nominal Weight	330-370 g/m	210-230 g/m



Blasting accessories

STEMPAC™

The STEMPAC is a stemming device constructed using Stemtite blast control plugs and crushed aggregate in a sealed plastic package. The STEMPAC enables blastholes that have been drilled horizontal or at an angle above horizontal to be stemmed. It is designed to be placed in a blasthole after the loading has been completed and be located 80cm below the explosive column. STEMPAC is available in three (3) different diameter sizes – 76mm, 89mm and 102mm.



Twin Twist Bell Wire

Insulation colour	Red and White Twist
Roll size	500 metres
Number of cores	2
Current rating (A)	1.8
Electrical Resistance @ 20°C(mΩ/m) per core	





Practical Innovations by Dyno Nobel Finally Made it Possible

What is DIFFERENTIAL ENERGY?

- Fast and accurate placement of up to six explosive densities with a single pass.
- Advancements in emulsion, mobile processing units and measure-while-drilling data that may result in greater downstream efficiencies.
- A safer alternative to typical blast hole loading techniques.
- Improved control that maximises Velocity of Detonation (VoD) and results in zero NOx events.



To learn how DIFFERENTIAL ENERGY can improve your blasting results contact: dnap.marketing@ap.dynonobel.com



Dyno Nobel Asia Pacific Pty Limited (ACN 003 269 010) is a subsidiary of incite: Pwot Limited (ACN 040 002 264). Level 8, 28 Freshwater Place, Southbark Vic 3006 © DVNO and DIFFERENTAL ENERGY are registered trademarks of the Dyno Nobel / Incite: Pwot Group, © Dyno Nobel Asia Pacific Pty Limited 2019. Reproduction without permission is strictly orphibited

Dyno Nobel Asia Pacific

Queensland

Principal Place of Business

282 Paringa Road Gibson Island Murarrie Qld 4172 Australia PO Box 3559 Tingalpa DC Qld 4173 Australia Telephone: +61 7 3026 3900 Fax: +61 7 3026 3999

New South Wales

Mt Thorley Technical Centre 5 Woodland Road Mt Thorley NSW 2330 Australia PMB 17 Singleton NSW 2330 Australia Telephone: +61 2 6574 2500 Fax: +61 2 6574 6849

Western Australia

Perth Office Suite 3, Level 2 Eastpoint Plaza 233 Adelaide Terrace Perth WA 6000 Australia Telephone: +61 8 6188 3000 Fax: +61 8 9325 4910

Indonesia

Jakarta Office

PT. dnx Indonesia Park View Plaza, 5 JI. Taman Kemang 2 No. 27 Jakarta Indonesia 12730 Telephone: +62 21 7179 4791 Fax: +62 21 7179 4794

Papua New Guinea

For PNG enquiries, contact the Gibson Island, Brisbane office.

www.dynonobel.com

DYNO[°] Dyno Nobel

Groundbreaking Performance[®]